


FIG. 3


:CARRIER DETECTION

```
:73AX2A MODE/73AX2 MODE/73AX MODE SWITCH
(COMBINED WITH CORE BOARD SETTINGS)
SETTING FOR CHECK OF RECEIVED LEVEL
MANUAL ADJUSTMENTS
   RECEIVED LEVEL RANGE SETTINGS
   DTE-SIDE TRANSMISSION SPEED SETTINGS
:DTE INTERFACE SETTINGS
:NOT IN USE
NOT IN USE
NOT IN USE
   DËLĂЎ TIME IN RELATION TO RS
ITINGS TO CHECK FOR CONTINUOUS TESTING
 DURING COUNTER RETURN TEST
SETTINGS TO CHECK FOR COUNTER RETURN
 TEST FUNCTION
   DATA TRANSMISSION CLOCK SOURCE SETTINGS
:ORIGINATION STATION MODEM SEND
 SIGNAL TIMING SETTINGS
:STI/TANDEM OPERATION SETTINGS
:NOT IN USE
:NOT IN USE
```




FISSA


Fig. 5.B



DEVICE CONTROL MODULE (FIRMWARE) READ-IN STATE



STATE OF FRONT PANEL SWITCHES








Fig.7A



CD LIN RL OPT MODO AX ~ 78




> TEST LED: OFF OTHERWISE:ON

Fig 7B

FIG. 8

B	00
_	

ORIGINATION STATION		DESTINATION STATION	
SWITCH	OPERATING CONDITIONS	OPERATING CONDITIONS	SWITCH
LP1	1.544 Mbps ST2	1.544 Mbps RT	LP2
LP3	1.536 Mbps ST2	1.536 Mbps RT	LP4
LP5	384 kbps ST2	384 kbps RT	LP6






FIG. 12

